

Wireless Handsets

4074 physical description



Mobility

The 4074's Charging Units

τ **4071 BA: Basic Charger**

One slot for the handset. No led, the handset displays the battery status

τ **4071 DA: Dual Charger**

Two slots: one for the handset, one for a spare battery. Two leds to control the

τ **4071 BC: Basic Comfort**

Same characteristics as the 4071 BA + loudspeaker for hands-free capability with the 4074GC .

Audio control knob.

	4071 BA	4071 DA	4071BC
LED	No	Status by red or green LED	No
Handset slot compatibility	4074 GB	4074 GB 4074 GI 4074 GB Ex	4074 GC
Wall mountable	Alone or by 6*	Alone or by 6*	Yes*
Fast charge	Handset (90 min)	Handset (90 min)	Handset (90 min)
Slow charge	No	Spare battery (8 h)	No



4071 BA



4071DA



4071 BC

Use of 4074 GI with headset

When a headset is plugged into a 4074 GI, the microphone and speaker are automatically switched-off.

Two ways to use a 4074 GI with a headset:



The manual off/on-hook

The auto off/on-hook: a programmable key must be dedicated to this feature. If activated, when a call arrives, the led flashes and a “bip” is sent in the headset (+ the usual information on the display) and after a time out, the call is automatically connected.